

1500CI Pelican Corrosion Intercept Kit Installation Instructions

STEP 1: CUT FILM TO SIZE

Cut the copper film to fit the length and width of the floor of your case.



STEP 2: LAY FILM IN CASE

Lay the cut film on the floor of the case underneath all foam layers. Do not use adhesive to affix the film.



STEP 3: PLACE FOAM OVER FILM

Place the foam on top of the film in the case.



STEP 4: PLACE FOAM FILTERS

Locate separate areas to place the foam indicating pads. For longer cases, we recommend placing them at either end of the case.



STEP 5: RENEW AS-NEEDED

Replace the corrosion kit (film and filters) as-needed. Foam will become green over time as contaminants become trapped within it, indicating replacement is required.

