



Fork Lift Riser Kit installation instructions P/N 3R-FLRK



Tools required include a marker, 1/4" drill, Philips screwdriver, 7/16" socket



Place riser foot in caster pocket on bottom of case and mark hole locations



Drill 1/4" hardware holes



Place riser foot back in caster pocket and install screws with a sealing washer from outside. You can see the screw heads and sealing washers in the picture on the right



Install sealing washer and then nylon lock nut from the inside and tighten hardware. Note that the washer will form around the one location with the bump.