



Reset Button

RESETTING YOUR OWN COMBINATION

Your new resettable combination padlock is preset to open at 0-0-0 (Even though dials may appear in other numbers.)

To Reset The Combination:

- STEP 1** Turn the dials to the preset combination and align the numbers to the Guide Line.
- STEP 2** Push the Reset Button with a pen (or other tools) all the way until complete turning the dials to your desired combination. (Do not let go of the button while setting the dials.)
- STEP 3** Release the Reset Button after changing to your own combination. Your lock is now ready to open at its new combination.

Keep your combination in a safe and accessible place for future reference.

Note:



The Transportation Security Administration (TSA) screeners and airline check-in staff at airports are trained to recognize the Travel Sentry logo. They understand that baggages with locks displaying this mark are permitted to remain locked.

TSA screeners have access to special codes that allow them to open these locks in the event that the baggages must be opened for inspection.

With Travel Sentry Certified locks the TSA can be screen checked baggage faster without having to break open locks.